

Keep for future reference

Terminal housing AC-2125





Use

NOTE



This manual is a part of the product. Read the manual carefully before using the product.

The AC-2125 is a terminal housing. With it, a number of types of installation can be realised.

Scope of Supply

No mounting screws are included in the scope of supply. Fittings:

- 8x M12x1,5 with brass plugs
- 2x M25x1,5 with brass plugs

Accessories pack:

- 8x EMV-fitting with O-ring
- 2x EMV-fitting with O-ring



User Manual AC-2125

Keep for future reference



Technical Data

Dimensions (B x L x H): 160 mm x 360 mm x 91 mm

Weight: 3 kg
Material: Aluminium
Outside paint: RAL 7032
Seal: HF Neusil
Rail: TS 35

Working temperature: -30 °C to +100 °C

Protection class: IP-66 according to EN 60529

Cable fittings: 8x M12 x 1,5 mm

Clamping range: 3 - 6,5 mm

Cable fittings: 2x M25 x 1,5 mm

Clamping range: 13 - 18 mm

Dimensioning




Figure 1) Dimensions of the AC-2125 terminal housing

Brüel & Kjær Vibro

ø 11 mm (housing)

ø 7 mm (housing

User Manual AC-2125

Keep for future reference

Assembly





- ⇒ Secure the terminal box to non-vibrating machine parts.
- ⇒ Observe the temperature (radiative heating) at the installation site.
- ⇒ For mounting you need a free surface of at least 360 mm x 160 mm.

Mounting the housing

The correct spacing of the drill holes is drawn on the back of the terminal box.

Holes for wall mounting

- 1. First, mark the positions for the drill holes.
- 2. Drill the four mounting holes.
- 3. Remove the housing cover.
- 4. Secure the housing: Screw in all 4 installation screws (Ø screw head < 10.5 mm).
- 5. Connect sensors.

NOTE



The cable fittings may limit the operating temperature. Take this into account for your installation.

6. Guide the incoming sensor lines through the cable fittings and connect the lines.

NOTE



Unused cable fittings may not be left open, as otherwise the IP protection is not ensured.


- \Rightarrow Ensure that the seals and seal surfaces are not soiled.
- 7. Close the unused cable fittings with the included plugs.
- 8. Put the housing cover back on: Screw on the cover with the 4 mounting screws.



User Manual AC-2125

Keep for future reference





- 1. Cable
- 2. Cap nut
- 3. Clamping piece
- 4. Inner O-ring
- 5. Cable shield
- 6. Connector

Figure 2) Layout of the cable shield in the cable fitting